

GETTING READY TO RACE

O REMOVE AIR FILTER

- STICK A CLOTH IN THE HOLE SO NO DIRT GETS IN
- SPRAY AIR FILTER AND COVER WITH AIR FILTER CLEANER.
- RINSE AIR FILTER AND COVER REALLY WELL
- SET ASIDE TO DRY, SPRAY FILTER LIGHTLY WITH AIR FILTER OIL
 WHEN DRY THEN PUT BACK ON KART

CHANGE OIL

- DRAIN OLD OIL
- ADD 13 oz OF NEW OIL

CLEAN CHAIN

- SPRAY CHAIN WITH BRAKE CLEAN WHILE SPINNING TIRES QUICKLY
- USING AIR HOSE TO SPRAY THE DIRT OUT OF THE CHAIN
- SPRAY CHAIN WITH CHAIN LUBE WHILE SPINNING TIRES QUICKLY

WRAP YOUR CLEAN TIRES

- SPRAY ALL FOUR TIRES WITH WD40 REALLY WELL
- COVER WITH PLASTIC WRAP
- CHECK ALL YOUR FASTENINGS TO MAKE SURE NOTHING IS LOOSE
- CLEAN YOUR KART INSIDE AND OUT
 - MARK SAYS "A CLEAN KART IS A FAST KART!"
- CLEAN UP YOUR WORK AREA



ON RACE DAY

O TIRES

- UNWRAP TIRES
- CHECK TIRE PRESSURES
 - ❖ 5 LBS ON THE OUTSIDE
 - ❖ 4 LBS ON THE INSIDE

O FUEL

- CHECK FUEL IS JUST ABOVE HALF WAY
- ADD AS NEEDED

AFTER PRACTICE & HEAT RACE

- WASH ALL TIRES & DRY THEM
- CLEAN KART OFF OF CHUNKS OF MUD
- CHECK TIRE PRESSURES

O AFTER FEATURE

- CLEAN TIRES
- WIPE DOWN YOUR GO KART
 - **❖** PUT KART AWAY CLEAN!